

RE-ARMING your HERO

Deflating

Always deflate your Hero product before rearming. Press down firmly into the top of the oral inflation tube using the top of the dust cap. Squeeze all air from the bladder ensuring it is completely empty. Rearming of Hero rash shirts and wetsuits can be carried out whilst being worn.



Check your Co2 Cartridge

Before using your Hero product always make sure the CO2 cartridge is full and has not been used previously. The CO2 cartridge is located in the top left pocket for both inflatable shirts and wetsuits. Simply unscrew the cartridge in an anticlockwise direction. If the seal is broken, the cartridge will need replacing.



Please note

It is very important that you replace used cartridges with the same size cartridge that your Hero product was supplied with. It is recommended that you replace the CO2 cartridge every 12 months, even if the cartridge has not been used. HERO recommends replacement with Hero refills only.

Inserting your new cartridge

Insert your new cartridge into the receiver and screw in a clockwise direction until firmly tight. Make sure that the pull chord/lanyard is secured in place by the green clip as shown in the photograph.

